



How to use the National Breast Implant Registry (NBIR) Paper Case Report Form (CRF):

- 1. Download and print the following documents from www.plasticsurgery.org/NBIR:
 - NBIR CRF
 - NBIR eFAX Cover Sheet

Please note – although these documents are not likely to change often, be sure to routinely check the website to ensure you are using the most current versions.

- **2.** Using black or blue pen, complete the NBIR CRF to the best of your ability—items marked with an asterisk (*) are required fields for Device Tracking and must be completed before submission to the NBIR.
- **3.** Add each device sticker (RIGHT and LEFT, if applicable) to the paper CRF.
- **4.** Review and complete the CRF for completeness and accuracy.
- **5**. Once the CRF is complete, **complete all of the fields on the NBIR eFAX Cover Sheet.**
- **6.** Please refer to the eFAX number found on the eFAX Cover Sheet, and fax both the cover sheet and CRF to the NBIR.
- **7.** Save the eFAX confirmation for your records.

